

ORIGINAL COLLECTION

## MANUAL



Originals are the beginning of a movement, the forerunners of the impossible.

Our Original Collection is the beginning of something bigger.

Built for precision and endurance, your new timepiece is ready to tackle the most extreme sports.

Because victory demands all you've got.

BE UNSTOPPABLE.

Alex Giren



01.	S-FORCE ORIGINAL Features	6
02.	Technical Specification	7
03.	How to set analog time	8
04.	Buttons functionality	10
05.	How to set digital time & date	12
06.	How to set daily alarm	14
07.	How to activate daily alarm, snooze & hourly chime	16
08.	Stopwatch operation - event & time-out timing	18
09.	Stopwatch - cumulative split timing (lap time)	19
10.	Warranty	20
11.	To Register Your S-Force ORIGINAL Watch	22
12.	Water Resistance	23



#### S-FORCE ORIGINAL FEATURES



Analog Hands: Hour & Minute
Digital Subdials: Hours, Minutes,
Month, Date & Day of the week
5 Minutes Snooze Alarm
SWISS Ronda Quartz 763 Movement
Instantaneous rate: -10- +20 sec/month
Standard Battery Life: 40 months
Jewels: 5, gold plated EDL

#### **TECHNICAL SPECIFICATIONS**

CASING	MECHANISM	BAND	OTHER FEATURES
CASE MATERIAL 316L Stainless Steel	MOVEMENT SWISS Quartz Ronda Movement	BAND & CLASP  Nitrile Rubber band with brass bar & stainless steel buckle	WARRANTY 2 Year Warranty
WATER RESISTANT 100WR (10ATM) Suitable for showering & surface swimming	DIGITAL SUBDIALS Hours, Minutes, Month, Date & Day of the week		HANDS & MARKERS Applied Steel Markers & Luminous hands
DIAL Beehive Effect & Silk Print	STANDARD BATTERY LIFE 40 months		INSTANTA- NEOUS RATE -10~ +20 sec/ month
CROWN Streamlined and Chamfered for Comfort	JEWELS 5. gold plated EOL		OTHER 5 Minutes Snooze Alarm
GLASS Sapphire Glass with Anti-reflective Coating	ANALOG HANDS Hour & Minute		

#### HOW TO SET ANALOG TIME

- Open the latch (pull up) on the right side of the watch face between R1 and R2, and pull out the crown gently
- 2. Rotate the crown left/right to adjust the time
- 3. Once set, push the crown back in and close the latch



### BUTTONS FUNCTIONALITY

- Default shows the time: hours (12 or 24 hours), minutes, month, date, and day of the week
- 2. Press L1 the display light turns on
- 3. Press R1 shows month, date, and the day of the week
- 4. Press L2 once enter Stopwatch mode.
- 5. Press L2 twice enter Alarm Set Mode (hours display will flash)
- 6. Press L2 three times enter Time Set Mode (seconds display will flash)
- Press R2 shows currently set Alarm Time.



### HOW TO SET DIGITAL TIME & DATE

- While on the default display, press L2 three times. Display will change to Time Set Mode. You will see the seconds digits flashing, press R1 to reset the seconds to zero (00).
- Press R2 once: Minutes digits will flash. Press R1 to set up minutes.
- 3. Press R2: Hour digits will flash, press R1 to set the hour. Advance to the desired hour. Keep pressing R1 to cycle through the 1-12 AM/PM (the 12 hours mode A and P will show next to the hour) to get to the 24 hours mode (H will show on display). Press R2 to keep setting date or Press L2 to return to the default display.
- 4. While on the default display, press L2 three times, then press R2 three times, the date will flash, press R1 to change the date; Press R2 once, the month will flash, press R1 to change the month, press R2 to set the month (not flashing now). Press R1: Day of the week flag will flash, press R2 to set the day of the week.
- 5. Press L2 to return to default display, and finish setting the time.



## HOW TO SET

- While on the default display Press L2 twice. Display will change to the Alarm Set Mode (note: only hour and minute will appear: 00:00; hour digits will flash).
- Press R1 to set the hour.
- 3. Press R2: Minutes will flash, press R1 to set the minutes.
- 4. Press L2 to return to default display, and finish setting alarm time.
- 5. To test the alarm sound, press and hold R1.



# HOW TO ACTIVATE DAILY ALARM, SNOOZE & HOURLY CHIME

- While on the default display, press and hold R2 then press R1 to turn the daily alarm ON or OFF (alarm sign in the upper right part of the display will appear when alarm is activated).
- When the daily alarm rings, press R2 to stop the alarm. This will activate
  the snooze feature, and the alarm will go off again after 5 minutes. Press
  R1 to stop the alarm without activating the snooze function.
- To activate hourly chime, Press and hold R2. Then, press L2 button to turn the hourly chime ON or OFF (when all the Day of Week flags are showing the hourly chime is ON).



# STOPWATCH OPERATION - EVENT AND TIME-OUT TIMING

- 1. While on the default display, press L2 once to enter Stopwatch Mode.
- 2. Press R1 to start the stopwatch.
- Press R1 again to stop the stopwatch.
- 4. Press R2 to reset the stopwatch to "00".
- 5. Press L2 once to return to the default display

# STOPWATCH - CUMULATIVE SPLIT TIMING (LAP TIME)

- 1. While on the default display, press L2 once to enter Stopwatch Mode.
- Press R1 to start the stopwatch.
- Press R2 to display cumulative split time (the stopwatch will continue to count internally).
- Press R2 to release the split time and display cumulative split time and display overall elapsed time in progress. This may be repeated as many times as necessary.
- Press R1 to stop counting, and press R2 to set up stopwatch to ".00".
- 6. Press L2 once to return to the default display

#### WARRANTY

We believe in our product and so should you!

Your S-Force™ watch comes with a full 2-year unlimited warranty from date of delivery.

If it breaks, we'll fix it. If we can't fix it, we'll replace it. Crystal to buckle, free of charge. It's that simple.

Our warranty covers watches purchased from the S-Force™ Official site, authorized retailers, or sponsored event.

In the event that your watch cannot be fixed but is no longer available, a watch of equal value and similar style will be provided.

All you need is your order number as proof of purchase or a copy of your receipt if purchased at an event. Was your watch a gift or have you lost your Order number? Leave the Proof of purchase field blank and send us your serial number with a picture of your backplate.



# TO REGISTER YOUR S-FORCE ORIGINAL WATCH

Your S-Force Original timepiece will have a unique and random serial number.

You may register your watch online at

www.sforcewatches.com/apps/product-registration

for expedited service.

To file a warranty claim, email us at <a href="mailto:support@sforcewatches.com">support@sforcewatches.com</a> along with your order confirmation number.

#### WATER RESISTANCE

Water Resistant 100WR (10ATM) - Your S-Force Original timepiece is suitable for showering, swimming, and shallow snorkeling. Splash/rain resistant.

METERS	÷	<b>₽</b>	<b>\(\tau\)</b>	Ħ	J	Ü
30M	~	×	×	×	×	×
50M	~	×	×	×	×	×
100M	~	~	~	~	~	×
200M	~	~	~	~	~	×

Please do not press buttons on the watch while the watch is wet (ex. while washing your hands or diving) as this might cause the water to permeate the seals. Make sure to keep your watch away from hot waters, steams and vapors.

## DISCOVER THE ORIGINAL COLLECTION



### STRENGTH OVERCOMES

SEORCEWATCHES COM